

420

for straight staircases

Armrests

Sturdy armrests are provided to help ease you comfortably in and out of the chair. The armrests fold up when not in use.

Directional Controls

Mounted on either arm of the chair, the low-pressure joystick will operate the stairlift in the required direction of travel. For safety the chair will only move while the joystick is pushed.

Swivel Levers

Swivel levers on either side allow the seat to be turned to face onto the top landing for safety. (Optional powered swivel available).

Rail

The stairlift travels along a narrow rail which encloses the mechanism. The rail stands on legs which attach to the stair treads, not the wall.

Seat belt

A lap-belt is fitted as standard. Other styles are available.

Safety Edges

Five sensitive safety edges immediately stop the stairlift if it meets an obstruction.

Arm-to-Footrest Link

Raise the armrest and the footrest folds up simultaneously.

Folding Seat

The seat, armrests and footrest fold up to leave the staircase clear for walking.

Remote Controls

Wireless controls on the wall at both ends of the staircase allow the stairlift to be moved to where it is needed. You can even send laundry or groceries on the chair.



The Stannah 420 is quiet, slim in profile and smooth riding. We utilize the most advanced technology to provide quick, clean installation and reliable performance.

Operation of the Stannah 420 couldn't be easier. A light touch on the joystick moves the stairlift up or down the stairs. At the top of the stairs the chair swivels for ease of exit. Remote controls are provided to enable you to call the stairlift to you, or send it to someone at the opposite end of the stairs.

Stannah and safety have always been synonymous. Every Stannah stairlift has a braking device and seat belt as standard equipment. Battery operation, complete with a continuous charge system, keeps your stairlift fully ready for use even in the event of a power failure. For safety and real convenience, the armrest and footrest are linked. Raise the armrest and the footrest folds up so you don't need to bend down to the floor to fold up the unit. That's very important at the top of the stairs.

Designed for safety and easy use, and built for your comfort, the Stannah 420 will blend beautifully into your home.

It's just the lift you need.

Batteries

Two standard 12 volt batteries allow the stairlift to operate in the event of a power outage. They also give a smooth, quiet ride. Recharging is automatic and continuous.

Key Switch

A key switch may be used to turn off the stairlift if, for instance, young children are around.



420

we're just the lift you need



The Stannah 420 swivels to face onto the top landing, putting the user in the safest position for getting into and out of the chair.

Contact



Design, manufacture and installation: Stannah model 420 and components have been tested and approved to BS 5776 1996, CSA, TUV, DLI, EU Type Approval to Machinery Directive 98/37/EC. Low voltage Directive 73/23/EEC and EMC Directive 89/336/EEC. Conforms to or exceeds ASME standards in the USA.

Our company policy is one of continuing product improvement. We therefore reserve the right to alter the specifications and to change and improve the design at any time. Full operating instructions are supplied for all products.


Stannah
Since 1862

Visit our website at www.stannah.com